Installation Instruction

Overview of filter package:

In the filter package, we provide multiple options of installation. Below is the overview of components included in this package.

				7	2 6 7 10	3 4 a) () () () () () () () () () () () () (
PART NO	QT	DISCRIPTION	PART NO	QT	DISCRIPTION	PART NO	QT	DISCRIPTION
1	1	Filter assembly	5	1	Filter housing wrench	9	2	Sheet metal tapping screw
2	1	Clear water tube	6	2	Clamp	10	2	Nylon lock nut
3	1	Barb hose fitting	7	2	Machine screw	11	2	Flat washer
4	1	Male garden hose fitting	8	2	Steel anchor			


Step 1: Connect filter assembly to output fittings:

- Barb hose fitting. Apply barb fitting to the "out" outlet. Attach the tube to the barb fitting with hose clamp;
- Male garden hose fitting: Apply garden hose fitting sub assembly to the "out" outlet. Garden hose is not provided in this package.



Step 2: Filter installation locations:

- Install filter on the side bar of pump with machine screws and nuts.



- Install filter on concrete/wood wall. In the package, we provided 2 steel anchors and 2 metal sheet tapping screws. If installed on wood surface, use only screws. If installed on concrete wall, apply anchors and screws together.

