

Installation Instruction

Step 1: Locate the input/output connection on the side of pump. As picture below, connection on the top is water output and the other is water input.



Step 2: We offered two available fittling configurations.

Option 1 : Output connects to high pressure compressed hose fitting
Input connects to female garden hose fitting



- Option 2: Output connects to high pressure compressed hose fitting Input connects to barb hose fitting

